
A short guide for using the SUPLA App.

Once the device has been successfully configured the added heater will appear on the **main screen** of the Application.



The main settings



The first temperature (19.20° C) - is measured with the remote / temp. sensor (H+R). This is the actual room temperature. The second (12° C) is the temperature set for the room.

By touching the buttons you can make the following adjustments:

- + button increase the temperature setting for the room
- button decrease the temperature setting for the room

ON / OFF button - switches the heater on or off

MANUAL - standard operating with +/- buttons on the right side of the screen

ECO - decreases the preset temperature in MANUAL mode by up to 5 deg.

TURBO - sets the heater to the max. heating temperature. Selection for 1 / 2 / 3 hours

AUTO - operating with daily/weekly program – the schedule is opened by the "clock" button on the upper bar.

(described in the next pages) In the AUTO mode "Pd" is displayed on the heater controller.

- opens the schedule for AUTO mode (to view or change the timings)
- opens the menu of temperature settings

Touching icon on the upper bar switches over from any screen to the main screen.

MANUAL mode













Important tips:

Auto mode - after a reset/power cut, the heater will always restart in Manual mode at 18°C, regardless of the pre-programmed temperature settings in Auto and Manual modes.


ECO mode – this mode corresponds only to **Manual mode**. If Eco mode is set to 5°C below the manual mode temperature, please ensure that Manual mode is NOT set below 15°C, otherwise, in the event of a reset/ power cut, the heater will restart in Eco at 21°C.

This matter will be resolved with a software change in the near future.

TURBO mode – in the event of a reset/power cut, this mode is cancelled, and the heater will restart in Manual mode.

Touching 1

opens the menu of temperature settings, which allows to set:



Change the duration of TURBO mode (1/2/3 hours)

The max. water temperature of the radiator

(from 30 to 70 deg. C)

Temperature reduction in ECO mode (from 1 to 5 deg.)

(Concerns the temperatures preset for MANUAL operating) The "Higher" temperature preset for AUTO mode

(from 10 to 30 deg. C)

The "Lower" temperature preset for AUTO mode (from 10 to 30 deg. C)


NOTICE: the "Lower" temperature must be at least 1 degree below the "Higher" one.



again switches back to the main settings screen.

Touching opens the schedule of AUTO mode.

An example of the schedule of AUTO mode (factory settings)



The schedule can be changed by touching the boxes.

The values of the temperatures are shown on the bottom of the screen. (preset in the temperature settings menu ()

Touching again switches over to the main settings screen.

Troubleshooting:





If a heater in the App has a red dot to the right, make sure that it is powered and switched on, and that it has an internet connection. Try restarting both the heater and the modem.


Please ensure that the router has enough available channels for new WiFi devices.

If a previously programmed heater loses connection to the internet, it will continue to work under the previous settings $\frac{1}{2} \int_{\mathbb{R}^{n}} \frac{1}{2} \left(\frac{1}{2} \int_{\mathbb{R}^{n}} \frac{1}{2} \left(\frac{$

If a yellow screen appears, please follow these suggestions.









The screen on the left can also signal an incorrect user name or password used in a previous step.
Check both and try again.

HEAT-POL 01.2023