





The heater should be installed by a qualified person.

Bathroom radiators fitted with electric heaters should be fixed not less than 60 cm from a bath, shower or wash basin, and never above a bath.

For the heater permanently connected (hard wire) there must be applied a cut-off device from the mains. Such a device must disconnect the heater from the supply mains in 2 poles, with contact separation of at least 3 mm. For version with a plug, the heater should be plugged in only to a socket with earthing contact. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children shall not play with the appliance Cleaning and user maintenance shall not be made by children without supervision The heater MUST BE DISCONNECTED before cleaning the casing. **AVOID SOAKING THE CASING**.

One radiator valve must always be open when a heater is in use (liquid thermal expansion).